

AQUATREADMILL
EASY LINE



HYDRORIDER®
PROFESSIONAL AQUATIC EQUIPMENT





PATENTED
Made in Italy

AQUATREADMILL EASY LINE



WWW.ZERONOVECOMUNICAZIONE.IT

The **Hydrorider AquaTreadmill Easy Line** has been created to give to fitness centres, recreation clubs, wellness-Spa centres and private pools the possibility to introduce aquatic running and walking into their facilities with the design and quality that distinguish Hydrorider products at a reasonable price.

It is a unique piece of equipment, light and foldable, it is made out of marine stainless steel AISI 316L (rust proof). The platform is made of 319 rolls that are rotating over flexible shock absorbing supports. There is neither mechanic resistance nor motor moving the rolls. The user has to move actively the legs impressing a force/movement toward the back contrasting the water resistance while the foot is sliding over the rolls, and again back to the front then starting a new step with the other leg.

Walking and running indoor is now a very popular activity on land and in water and it has few to none side effects. Particularly in water, we will dramatically reduce the weight effect on our body improving balance, muscular perception and blood circulation.

Hydrorider has made this easier and more affordable with the new Hydrorider AquaTreadmill Easy Line that allows the user to walk and run while immersed in the water taking advantage of the buoyancy and other benefits of the aquatic environment.

The AquaTreadmill Hydrorider Easy Line is a multipurpose piece of equipment perfect for group exercise, circuit training, physical therapy, rehabilitation, personal training and athletic training. With special population it can be utilized for people with limitations due to arthritis, fibromyalgia, previous injury, obesity or those who are de-conditioned, also suitable for coop use with medical and fitness facilities. It can be easily folded and stored after its use.

ADVANTAGES FOR THE FITNESS CENTER

- Affordable investment
- Easy to store
- Attracts the attention of new client types across all age groups and increase your customer base.
- Versatility and applicability in different types of training.
- Safe and durable.
- Low maintenance.

ADVANTAGES FOR THE USERS

- Easy to handle.
- Light, steady and foldable.
- Easy to use for all clients.
- Simplifies instructors job.
- Excellent equipment for circuit training.

The **Hydrorider Aquatreadmill Easy Line** also features the attraction to seasonal pool facilities, aqua parks, hotels and private pools.

GENERAL INFO

Pool Depth – Ideal Pool depth is 4' to 5' (120cm-150cm).

The buoyancy property - allows the user to walk and run providing a stress free training for the joints avoiding the traumas caused by walking and running on land.

Maintenance - The equipment does not require any special care. We recommend to periodically check the conditions of the base rubber protection.

Storage - The Treadmills can be stored or left on the deck or in the water.

Special recommendation - The use of the treadmills in thermal, salt and mineral rich waters requires more attention: rinse the equipment with fresh water and towel dry them when taken out of the pool. Periodically use a stainless still cleaning solution to help prevent deposits of metals or chemicals.

Warranty – 2 years

TECHNICAL SPECIFICATIONS

- Marine Stainless steel AISI 316L rust proof.
- Wheels for easy handling
- Foldable for easy storage
- Double anti skid rubber protection on bases



Dimintions Opened

- Length 47" / 120 cm
- Width base 32" / 80 cm
- Height 51" / 130 cm

Dimintions Folded

- Length 22" / 55 cm
- Width base 32" / 80 cm
- Height 51" / 130 cm

Box Dimintions

- Lenght 48" / 123 cm
- Widht 8" / 21 cm
- Keight 28" / 70 cm
- Weight 77 lbs / 35 kg

HYDRORIDER EUROPE

Via della Tecnica 75 - 40068 San Lazzaro di Savena (BO) - Italy
Tel: +39 051 461110 - +39 335 1316545 - Fax: +39 051 463090
www.hydrorider.com - info@hydrorider.com

HYDRORIDER USA

11130 Griffing Blvd. - Biscayne Park, FL 33161 - U.S.A.
Telephone & Fax +1 305 762 7557
www.hydroriderusa.com - usa@hydrorider.com